

## Steps

- 1 | **Start the sale transaction**
- 2 | Press 0 for sale
- 3 | Select Credit or Debit
- 4 | Enter the sale amount
- 5 | Insert chip card
- 6 | Leave chip card inserted
- 7 | Sale approved
- 8 | Terminal prints receipt
- 9 | Customer receipt prints
- 10 | Sale complete



### Step 1

Start the sale transaction

Press the green **Enter** key.

## Steps

- 1 | Start the sale transaction
- 2 | **Press 0 for sale**
- 3 | Select Credit or Debit
- 4 | Enter the sale amount
- 5 | Insert chip card
- 6 | Leave chip card inserted
- 7 | Sale approved
- 8 | Terminal prints receipt
- 9 | Customer receipt prints
- 10 | Sale complete




### Step 2

## Press 0 for sale

Press the **0** key to begin a sale transaction.

## Steps

- 1 | Start the sale transaction
- 2 | Press 0 for sale
- 3 | **Select Credit or Debit**
- 4 | Enter the sale amount
- 5 | Insert chip card
- 6 | Leave chip card inserted
- 7 | Sale approved
- 8 | Terminal prints receipt
- 9 | Customer receipt prints
- 10 | Sale complete




### Step 3

Select Credit or Debit

EXAMPLE: Press **1** for credit card sale transaction.

## Steps

- 1 | Start the sale transaction
- 2 | Press 0 for sale
- 3 | Select Credit or Debit
- 4 | **Enter the sale amount**
- 5 | Insert chip card
- 6 | Leave chip card inserted
- 7 | Sale approved
- 8 | Terminal prints receipt
- 9 | Customer receipt prints
- 10 | Sale complete



### Step 4

Enter the sale amount

Use the key pad to enter the sale amount and press the green **Enter** key.

## Steps

- 1 | Start the sale transaction
- 2 | Press 0 for sale
- 3 | Select Credit or Debit
- 4 | Enter the sale amount
- 5 | **Insert chip card**
- 6 | Leave chip card inserted
- 7 | Sale approved
- 8 | Terminal prints receipt
- 9 | Customer receipt prints
- 10 | Sale complete



### Step 5

## Insert chip card

If your machine is set up to accept debit with PIN, the customer can choose *U.S. debit*, which will prompt them to key in their PIN and then press the green **Enter** key.

Otherwise, they can choose *Visa debit*, as in this example. If it is a MasterCard®, the option to choose will be labeled *MasterCard debit*.

## Steps

- 1 | Start the sale transaction
- 2 | Press 0 for sale
- 3 | Select Credit or Debit
- 4 | Enter the sale amount
- 5 | Insert chip card
- 6 | **Leave chip card inserted**
- 7 | Sale approved
- 8 | Terminal prints receipt
- 9 | Customer receipt prints
- 10 | Sale complete



### Step 6

Leave chip card inserted

The screen will display the message *Verifying Card*.

## Steps

- 1 | Start the sale transaction
- 2 | Press 0 for sale
- 3 | Select Credit or Debit
- 4 | Enter the sale amount
- 5 | Insert chip card
- 6 | Leave chip card inserted
- 7 | **Sale approved**
- 8 | Terminal prints receipt
- 9 | Customer receipt prints
- 10 | Sale complete



### Step 7

## Sale approved

Once the sale is approved, remove the card and press the green **Enter** key.

## Steps

- 1 | Start the sale transaction
- 2 | Press 0 for sale
- 3 | Select Credit or Debit
- 4 | Enter the sale amount
- 5 | Insert chip card
- 6 | Leave chip card inserted
- 7 | Sale approved
- 8 | **Terminal prints receipt**
- 9 | Customer receipt prints
- 10 | Sale complete



### Step 8


## Terminal prints receipt

The merchant and customer copies of the receipt will automatically print, depending on the set-up. The customer will sign the receipt, if required.



## Steps

- 1 | Start the sale transaction
- 2 | Press 0 for sale
- 3 | Select Credit or Debit
- 4 | Enter the sale amount
- 5 | Insert chip card
- 6 | Leave chip card inserted
- 7 | Sale approved
- 8 | Terminal prints receipt
- 9 | **Customer receipt prints**
- 10 | Sale complete



### Step 9

## Customer receipt prints

Press the green **Enter** key to print the customer receipt.

## Steps

- 1 | Start the sale transaction
- 2 | Press 0 for sale
- 3 | Select Credit or Debit
- 4 | Enter the sale amount
- 5 | Insert chip card
- 6 | Leave chip card inserted
- 7 | Sale approved
- 8 | Terminal prints receipt
- 9 | Customer receipt prints
- 10 | **Sale complete**



### Step 10

## Sale complete

The sale is complete; the main menu screen displays.